1. Precautions

- 1. Warning: Prior to repair, disconnect the power cord from the circuit breaker.
- 2. Use proper parts: Use only exact replacement parts. (Also, we recommend replacing parts rather than repairing them.)
- 3. Use the proper tools: Use the proper tools and test equipment, and know how to use equipment may cause problems later-intermittent contact, for example.
- 4. Power Cord: Prior to repair, check the power cord and replace it if necessary.
- 5. Avoid using an extension cord, and avoid tapping into a power cord. This practice may result in malfunction or fire.
- 6. After completing repairs and reassembly, check the insulation resistance, Procedure: Prior to applying power, measure the resistance between the power cord and the ground terminal. The resistance must be greater than 30 megohms.
- 7. Make sure that the grounds are adequate.
- 8. Make sure that the installation conditions are satisfactory. Relocate the unit if necessary.
- 9. Keep children away from the unit while it is being repaired.
- 10. Be sure to clean the unit and its surrounding area.




Fig. 1-1 Avoid Dangerous Contact




Fig. 1-2 No Tapping and No Extension Cords




Fig. 1-3 No Kids Nearby!




Fig. 1-4 Clean the Unit

Samsung Electronics 1-1