



ROOM AIR CONDITIONER

INDOOR UNIT



SH07ZS2
SH07ZS2A
SH09ZS2
SH09ZS2A
SH12ZS4
SH12ZS4A
AQ07S2GE
AQ09S2GE
AQ12S4GE
AQT12S4GB
AQT12S4GE

OUTDOOR UNIT

SH07ZS2X
SH07ZS2AX
SH09ZS2X
SH09ZS2AX
SH12ZS4X
SH12ZS4AX
UQ07S2GE
UQ09S2GE
UQ12S4GE
UQT12S4GB
UQT12S4GE

SERVICE Manual

AIR CONDITIONER



CONTENTS

1. Product Specifications
2. Operating Instructions
3. Disassembly and Reassembly
4. Refrigerating Cycle Diagram
5. Set Up the Model Option
6. Troubleshooting
7. Exploded Views and Parts List
8. Block Diagram
9. PCB Diagram
10. Wiring Diagram
11. Schematic Diagram