




ROOM AIR CONDITIONER

INDOOR UNIT
AQV12F2VE

OUTDOOR UNIT
UQV12A0TE

SERVICE Manual

AIR CONDITIONER



CONTENTS

1. Precautions
2. Product Specifications
3. Operating Instructions and Installation
4. Disassembly and Reassembly
5. Troubleshooting
6. Exploded Views and Parts List
7. PCB Diagrams
8. Wiring Diagrams

