




CASSETTE TYPE AIR CONDITIONER

(Cool and Heat)

Type	Indoor Unit	Outdoor Unit	Panel
ACH1800E(1)	ICH1800E	UBH1800E	IFS095G00/01
ACH2400E(1)	ICH2400E	UBH2400E	IFS095G00/01
ACH3600G(1)	ICH3600G	UCH3600G	IFS095G00/01
ACH4400G(1)	ICH4400G	UCH4400G	IFS095G00/01
CH18ZA	CH18ZA	CH18ZAX	CH01(02)ZAP
CH24ZA	CH24ZA	CH24ZAX	CH01(02)ZAP
CH36ZA	CH36ZA	CH36ZAX	CH01(02)ZAP
CH44ZA	CH44ZA	CH44ZAX	CH01(02)ZAP
CH18CA	CH18CA	CH18CAX	CH01(02)ZAP
CH24CA	CH24CA	CH24CAX	CH01(02)ZAP
CH36CA	CH36CA	CH36CAX	CH01(02)ZAP
CH44CA	CH44CA	CH44CAX	CH01(02)ZAP

SERVICE *Manual*

AIR CONDITIONER



CONTENTS

1. Precautions
2. Product Specifications
3. Operating Instructions
4. Installation
5. Disassembly and Reassembly
6. Troubleshooting
7. Exploded Views and Parts List
8. Block Diagrams
9. PCB Diagrams
10. Schematic Diagrams
11. Wiring Diagrams